



Brake pad cross-references Ebc

2010-11-11

Ebc	Magnum
FA 18	AT018
FA 29; 30; 31	AT030;AT031
FA 34	AT034
FA 36	AT036
FA 45	AT045
FA 47;516	AT047
FA 50	AT050
FA 51	AT051
FA 54	AT054
FA 60;337	AT060;AT3371
FA 63	AT063
FA 65	AT065
FA 66; 68	AT066;AT068
FA 67;372	AT067;AT3721
FA 69	AT069
FA 70	AT070
FA 76	AT076
FA 80	AT080
FA 81	AT081
FA 83	AT083
FA 84	AT084
FA 84/3	AT084/3
FA 85	AT085
FA 86	AT086
FA 88	AT088
FA 90	AT090
FA 92;323	AT092;AT3231
FA 93	AT093
FA 94	AT094
FA 95	AT095
FA 99	AT099
FA100	AT1001
FA101	AT1011
FA103	AT1031
FA104	AT1041
FA105	AT1051
FA106	AT1061
FA109	AT1091
FA110	AT1101
FA111	AT1011
FA113;256	AT1131;AT2561
FA115	AT1151
FA116	AT1161
FA118	AT1181
FA119	AT1191
FA121;203	AT1211;AT2031
FA122	AT1221
FA123	AT1231
FA124	AT1241;AT4121
FA125;143	AT1251;AT1431
FA126	AT1261
FA128	AT1281
FA129	AT1291
FA130	AT1301
FA131	AT1311
FA131/3;233	AT2331
FA132	AT1321
FA134	AT1341
FA135;214;228	AT1351;AT2281
FA136	AT1361
FA137	AT1371
FA140	AT1401
FA141	AT1411



Brake pad cross-references Ebc

2010-11-11

Ebc	Magnum
FA142;226	AT1421;AT2261
FA144;187	AT1441;AT1871
FA145	AT1451
FA146	AT1461
FA147	AT1471
FA150	AT1501
FA151	AT1511
FA152	AT1521
FA153	AT1531
FA155	AT1551
FA156	AT1561
FA157	AT1571
FA158	AT1581
FA159	AT1591
FA160	AT1601
FA161	AT1611
FA162	AT1621
FA163	AT1631
FA164	AT1641
FA165;197;215	AT1651;1971
FA167	AT1671
FA168;252;380	AT2521;AT3801
FA169	AT1691
FA171	AT1711
FA172	AT1721
FA173	AT1731
FA174	AT1741
FA177	AT1771
FA179	AT1791
FA180	AT1801
FA181;245	AT1811;AT2451
FA182	AT1821
FA185;389	AT1851;AT3891
FA186	AT1861
FA188	AT1881
FA189	AT1891
FA190	AT1901
FA191	AT1911
FA192	AT1921
FA193	AT1931
FA194	AT1941
FA196	AT1961
FA198	AT1981
FA199	AT1991
FA200	AT2001
FA201	AT2011
FA206	AT2061
FA208;213	AT2081;AT2131
FA209	AT2091
FA210	AT2101
FA220	AT2201
FA222	AT2221
FA229	AT2291
FA230;396	AT2301;AT3961
FA231;259	AT2311;AT2591
FA232	AT2321
FA234	AT2341
FA235	AT2351
FA236	AT2361
FA239	AT2391
FA243	AT2431
FA244	AT2441
FA246;407	AT2461;AT4071



Brake pad cross-references Ebc

2010-11-11

Ebc	Magnum
FA249;424	AT2491;AT4241
FA254	AT2541
FA255	AT2551
FA257	AT2571
FA258;349	AT2581;AT3491
FA260	AT2601
FA261;281	AT2611;AT2811
FA264	AT2641
FA265	AT2651
FA266	AT2661
FA267	AT2671
FA268	AT2681
FA270	AT2701
FA271;533	AT2711
FA273	AT2731
FA275	AT2751
FA282	AT2821
FA283	AT2831
FA291	AT2911
FA294	AT2941
FA298	AT2981
FA299	AT2991
FA301	AT3011
FA302	AT3021
FA303	AT3031
FA304	AT3041
FA305	AT3051
FA306	AT3061
FA307	AT3071
FA313	AT3131
FA314	AT3141
FA317	AT3171
FA319	AT3191
FA320	AT3201
FA321	AT3211
FA322	AT3221
FA324	AT3241
FA325	AT3251
FA3340	
FA335	AT3351
FA336	AT3361
FA342	AT3421
FA343	AT3431
FA344	AT3441
FA345	AT3451
FA346	AT3461
FA347	AT3471
FA348	AT3481
FA350	AT3501
FA351	AT3511
FA352	AT3521
FA353	AT3531
FA354	AT3541
FA355	AT3551
FA356	AT3561
FA357	AT3571
FA358	AT3581
FA363	AT3631
FA366	AT3661
FA367	AT3671
FA368	AT3681
FA369	AT3691
FA373	AT3731



Brake pad cross-references Ebc

2010-11-11

Ebc	Magnum
FA374	AT3741
FA375	AT3751
FA377	AT3771
FA379	AT3791
FA381	AT3811
FA382	AT3821
FA384	AT3841
FA387	AT3871
FA388	AT3881
FA390	AT3901
FA393	AT3931
FA395	AT3951
FA398	AT3981
FA399	AT3991
FA400	AT4001
FA401	AT4011
FA403	AT4031
FA405	AT4051
FA406	AT4061
FA408	AT4081
FA409	AT4091
FA410	AT4101
FA411	AT4111
FA412	AT4121
FA413	AT4131
FA414	AT4141
FA415	AT4151
FA416	AT4161
FA417	AT4171
FA418	AT4181
FA419	AT4191
FA423	AT4231
FA425	AT4251
FA427	AT4271
FA428	AT4281
FA430	AT4301
FA431	AT4311
FA432	AT4321
FA433	AT4331
FA434	AT4341
FA435	
FA436	AT4361
FA438	
FA441	
FA442/4	AT442/41
FA443	AT4431
FA444	AT4441
FA445	AT4451
FA446	AT4461
FA447	AT4471
FA450	AT4501
FA452	AT4521
FA456	AT4561
FA457	AT4571
FA458	AT4581
FA460	
FA462	AT4621
FA463	AT4631
FA464	AT4641
FA465	AT4651
FA468	
FA473	
FA474	



Brake pad cross-references Ebc

2010-11-11

Ebc	Magnum
FA482	
FA483	
FA488	
FA489	
FA501	
FA502;502A	
FA502B	
FA503	
FA503A;526	
FA504	
FA504B	
FA504C	
FA506	
FA506A	
FA507	
FA509	
FA509A	
FA510	
FA511	
FA512	
FA513	
FA514A	
FA515	
FA516	
FA517	
FA518	
FA519	
FA523	
FA524	
FA525	
FA525A	
FA527	
FA528	
FA529	
FA530	
FA531	
FA533	
FA534	
FA535	